



TI-Innovator™ System Setup Guide

This guidebook applies to TI-Innovator™ Hub software version 1.2. To obtain the latest version of the documentation, go to education.ti.com/guides.

Important Information

Except as otherwise expressly stated in the License that accompanies a program, Texas Instruments makes no warranty, either express or implied, including but not limited to any implied warranties of merchantability and fitness for a particular purpose, regarding any programs or book materials and makes such materials available solely on an "as-is" basis. In no event shall Texas Instruments be liable to anyone for special, collateral, incidental, or consequential damages in connection with or arising out of the purchase or use of these materials, and the sole and exclusive liability of Texas Instruments, regardless of the form of action, shall not exceed the amount set forth in the license for the program. Moreover, Texas Instruments shall not be liable for any claim of any kind whatsoever against the use of these materials by any other party.

Learning More with the TI-Innovator™ System eGuide

Parts of this document refer you to the TI-Innovator™ System eGuide for more details. The eGuide is a Web-based source of TI-Innovator™ information, including:

- Programming with the TI CE Family of Graphing Calculators and TI-Nspire™ Technology, including sample programs.
- Available I/O Modules and their commands.
- Available breadboard components and their commands.
- Available TI-Innovator™ Rover and its commands.
- Link to update the TI-Innovator™ Sketch software.
- Free classroom activities for TI-Innovator™ Hub.

Apple®, Chrome®, Excel®, Google®, Firefox®, Internet Explorer®, Mac®, Microsoft®, Mozilla®, Safari®, and Windows® are registered trademarks of their respective owners.

QR Code® is a registered trademark of DENSO WAVE INCORPORATED.

Select images were created with Fritzing.

© 2011 - 2017 Texas Instruments Incorporated

Contents

Important Information ii

 Learning More with the TI-Innovator™ System eGuide ii

TI-Innovator™ System Overview 1

 Learn More 1

What's in the Box 2

 TI-Innovator™ Hub with On-Board Components 2

 Built-in Ports 2

 USB Cables 3

 Auxiliary Power 3

Connecting TI-Innovator™ Hub 4

 Connecting to a Graphing Calculator 4

 Connecting to a Computer Running TI-Nspire™ CX Software 5

Using an Auxiliary Power Source 6

 Connecting the Power Source 6

General Precautions 8

 TI-Innovator™ Hub 8

 Breadboard Connector on the Hub 8

TI-Innovator™ Hub Software License Agreement 9

General Information 16

 Texas Instruments Support and Service 16

 General Information: North and South America 16

 For Technical Support 16

 For Product (Hardware) Service 16

 For All Other Countries: 16

 Service and Warranty Information 16

TI-Innovator™ System Overview

The TI-Innovator™ System consists of TI-Innovator™ Hub with TI LaunchPad™ Board, and optional TI-Innovator™ components.

The TI-Innovator™ Hub lets you use your compatible TI graphing calculator or TI-Nspire™ CX computer software to control components, read sensors, and create powerful learning experiences.

- You communicate with the Hub through TI Basic programming commands.
- Hosts that are compatible with TI-Innovator™ Hub include:
 - TI CE Family of Graphing Calculators (TI-83 Premium CE, TI-84 Plus CE, and TI-84 Plus CE-T) with operating system version 5.3 or later installed. You also need to install or update the Hub App, which contains the Hub menu.
 - TI Nspire™ CX or TI Nspire™ CX CAS handheld with operating system version 4.5 or later installed
 - TI Nspire™ computer software version 4.5 or later
- **TI-Innovator™ Hub.** Communicates with the host, the Hub on-board components, and connected external components. It also distributes power to external components.
- **TI-Innovator™ Components.** These components, sold separately, include sensors, motors, and LEDs that connect to the Hub through its I/O ports and breadboard connector.

Learn More

For a list of precautions to take while using the Hub and its components, refer to *General Precautions* (page 8).

To find information on accessories, external modules, and breadboard components, visit education.ti.com/go/innovator.


What's in the Box

TI-Innovator™ Hub with On-Board Components

- ❶ A Light Brightness Sensor at the bottom of the Hub can be read as "BRIGHTNESS" in Hub command strings.
- ❷ Red LED is addressable as "LIGHT" in Hub command strings.
- ❸ Speaker (at back of Hub, not shown) is addressable as "SOUND" in Hub command strings.
- ❹ Red-Green-Blue LED is addressable as "COLOR" in Hub command strings.

Also visible on the face of the Hub are:


- Ⓐ Green auxiliary power LED
- Ⓑ Green power LED,
- Ⓒ Red error LED.



Built-in Ports


Left side - Three ports for collecting data or status from input modules:

- **IN 1** and **IN 2** provide 3.3V power.
- **IN 3** provides 5V power.



Right side - Three ports for controlling output modules:

- **OUT 1** and **OUT 2** provide 3.3V power.
- **OUT 3** provides 5V power.




Bottom - Light Brightness Sensor (described earlier) and two ports:

- **I²C** port connects to peripherals that use the I²C communication protocol.
- **DATA** Mini-B port, used with the appropriate cable, connects to a compatible graphing calculator or computer for data and power.




Top - Two connectors:

- USB-Micro connector (**PWR**) for auxiliary power required by some components. Also used for updating the Hub internal software.
- Breadboard Connector with 20 labeled pins for communication with connected components. A breadboard and jumper cables are included with the TI-Innovator™ Breadboard Pack, sold separately.



USB Cables



- 1 USB Unit-to-Unit (Mini-A to Mini-B) - Connects the Hub to a TI CE Graphing Calculator or a TI-Nspire™ CX Handheld.
- 2 USB Standard A to Mini-B - Connects the Hub to a computer running TI-Nspire™ CX Software.
- 3 USB Standard A to Micro - Connects the **PWR** port of the Hub to a TI approved power source required by some peripherals.

Auxiliary Power

TI Wall Charger - Supplies power through the TI-Innovator™ Hub for components, such as motors, that require additional power.

The optional External Battery Pack can also provide auxiliary power.

Note: An auxiliary power LED on the Hub indicates when the Hub is receiving auxiliary power.




Connecting TI-Innovator™ Hub

The TI-Innovator™ Hub connects by a USB cable to a graphing calculator or computer. The connection lets the Hub receive power and exchange data with the host.

Note: Some peripherals, such as motors, may require auxiliary power. For more information, see Using an Auxiliary Power Source (page 6).

Connecting to a Graphing Calculator

1. Identify the "B" connector on the USB Unit-to-Unit (Mini-A to Mini-B) cable. Each end of this cable is embossed with a letter.
2. Insert the "B" connector into the **DATA** port at the bottom of the TI-Innovator™ Hub.



3. Insert the free end of the cable (the "A" connector) into the USB port on the calculator.



Hub connected to TI CE
Graphing Calculator



Hub connected to TI-Nspire™ CX Handheld

4. Turn on the calculator if it is not already on.

The power LED on the Hub glows green to show that it is receiving power.

Connecting to a Computer Running TI-Nspire™ CX Software

1. Identify the "B" connector on the USB Standard A to Mini-B cable for Windows®/Mac®. Each end of this cable is embossed with a letter.
2. Insert the "B" connector into the **DATA** port at the bottom of the TI-Innovator™ Hub.
3. Insert the free end of the cable (the "A" connector) into a USB port on the computer.

The power LED on the Hub glows green to show that it is receiving power.



Using an Auxiliary Power Source

Normally, the TI-Innovator™ Hub and its connected components draw power from the host calculator or computer, through the **DATA** connector. Certain components, such as the optional Servo Motor, require more power than a calculator can provide reliably.

The **PWR** connector on the Hub lets you connect an auxiliary power source. You can use the TI Wall Charger or the External Battery Pack.

TI Wall Charger (included with the Hub)

- Plugs into a wall outlet.
- Does not use batteries.



External Battery Pack (sold separately)


- Rechargeable.
- Has On/Off button with a row of LEDs that momentarily indicate the battery charge when you turn the battery on.
- Turns itself off after being disconnected from the Hub for about 3 minutes.



Note: To recharge the External Battery Pack, disconnect it from the Hub and then connect it to the TI Wall Charger using the USB Standard A to Micro cable. Do not use the External Battery Pack as an auxiliary power source while it is being charged.

Connecting the Power Source

1. Identify the Micro connector on the USB Standard A to Micro auxiliary power cable.
2. Insert the Micro connector into the **PWR** connector at the top of the Hub.



3. Insert the free end of the cable (the "A" connector) into the USB port on the power source.
4. Turn on the power source:
 - If using the TI Wall Charger, plug it into a wall socket.
 - If using the External Battery Pack, press the power button.

An auxiliary power LED on the Hub glows to show that the Hub is receiving auxiliary power.

5. Connect the TI-Innovator™ Hub to the host calculator, using the USB Standard A to Mini-B cable.
6. Connect the I/O Module or breadboard component to the Hub.

General Precautions

TI-Innovator™ Hub

- Do not expose the Hub to temperatures above 140°F (60°C).
- Do not disassemble or mistreat the Hub.
- Do not chain together multiple Hubs through the I/O ports or the Breadboard Connector.
- Use only the USB cables provided with the Hub.
- Use only the TI provided power supplies:
 - TI Wall Charger included with the TI-Innovator™ Hub
 - Optional External Battery Pack
 - 4AA battery holder included in the TI-Innovator™ Breadboard Pack
- Ensure that the components receiving power from the Hub do not exceed the Hub's 1-amp power limit.
- Avoid using the Hub to control AC electricity.

Breadboard Connector on the Hub

- Do not insert the leads of LEDs and other components directly into the Hub's Breadboard Connector. Assemble the components on the breadboard and use the provided jumper cables to connect the breadboard to the Hub.
- Do not connect the 5V receptacle pin on the Hub's Breadboard Connector to any of the other pins, especially the ground pins. Doing so could damage the Hub.
- Connecting the top row of receptacle pins (BB1-10) to the bottom row (grounding and power pins) is not recommended.
- No pin on the Hub's Breadboard Connector can sink or source greater than 4 mA.



TI-Innovator™ Hub Software License Agreement

AMERICAS

TI-Innovator™ Hub Software Single User License

APPLICATION: This Single User License applies to TI-Innovator™ Hub obtained in the United States or Canada.

IMPORTANT - Read this agreement ("Agreement") carefully before using the Texas Instruments TI-Innovator™ Hub ("TIH"). The software program(s) installed on the TIH and materials accompanying it are licensed, not sold. By using the software program(s) contained on the TIH, you agree to be bound by the terms of this license. If you do not agree with the terms of this license, return the TIH and its package with all its contents to the place of purchase for a full refund.

The software program(s) in this installation and any related documentation (collectively referred to as the Program) are licensed, not sold, by Texas Instruments Incorporated (TI) and/or any applicable licensors (collectively referred to as Licensor). Specific details of the license granted are set forth below.

SINGLE USER LICENSE

Licensor grants to you a personal, non-exclusive, non-transferable license to install and use the Program on a TIH. You may make one copy of the software for backup and archival purposes. You agree to reproduce all copyright and proprietary notices shown in the software and on the media. Unless otherwise expressly stated in the documentation, you may not duplicate such documentation.

You agree that you will not reverse-assemble or reverse-compile the software program portion of the Program. This license shall automatically terminate in the event you attempt to reverse assemble or reverse-compile the software program portion of the Program or defeat any software protection mechanism contained within the software program portion of the Program. You may not sell, rent, lease or otherwise transfer the Program or any copies, whether in whole or in part.

Additional Terms Applicable To The Holder Of A Single User License:

WARRANTY DISCLAIMER AND DAMAGES EXCLUSIONS AND LIMITATIONS

Warranty. Licensor does not warrant that the Program will be free from errors or will meet your specific requirements. Any statements made concerning the utility of the Program are not to be construed as express or implied warranties.

LICENSOR MAKES NO CONDITIONS OR WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED CONDITIONS OR WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT REGARDING THE PROGRAM AND MAKES THE PROGRAM AVAILABLE ON AN "AS IS" BASIS.

LICENSOR SHALL NOT BE RESPONSIBLE FOR ANY DAMAGES CAUSED BY THE USE OF THE PROGRAM, OR SUFFERED OR INCURRED BY YOU OR ANY OTHER PARTY INCLUDING BUT NOT LIMITED TO SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF LICENSOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME STATES OR PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OR

LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS, THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

LICENSOR'S TOTAL AGGREGATE LIABILITY UNDER THIS LICENSE IS LIMITED TO 500 (FIVE HUNDRED) US\$.

THE ABOVE LIMITATIONS OF LIABILITY FOR DAMAGES DO NOT APPLY IN CASE OF CAUSATION OF BODILY HARM DUE TO LICENSOR'S FAULT, IN CASE OF DAMAGES DUE TO LICENSOR'S GROSS NEGLIGENCE OR INTENT OR IF LICENSOR IS LIABLE UNDER MANDATORY PRODUCT LIABILITY LAWS.

GENERAL

This Agreement will immediately terminate if you fail to comply with its terms. Upon termination of this Agreement, you agree to return or destroy the original package and all whole or partial copies of the Program in your possession and so certify in writing to TI.

The export and re-export of United States original software and documentation is subject to the Export Administration Act of 1969 as amended. Compliance with such regulations is your responsibility. You agree that you do not intend to nor will you, directly or indirectly, export, re-export or transmit the Program or technical data to any country to which such export, re-export or transmission is restricted by any applicable United States regulation or statute, without the proper written consent or license, if required of the Bureau of Export Administration of the United States Department of Commerce, or such other governmental entity as may have jurisdiction over such export, re-export or transmission.

If the Program is provided to the U.S. Government pursuant to a solicitation issued on or after December 1, 1995, the Program is provided with the commercial license rights and restrictions described elsewhere herein. If the Program is provided to the U.S. Government pursuant to a solicitation issued prior to December 1, 1995, the Program is provided with "Restricted Rights" as provided for in FAR, 48 CFR 52.227-14 (JUNE 1987) or DFAR, 48 CFR 252.227-7013 (OCT 1988), as applicable.

Manufacturer is Texas Instruments Incorporated, 12500 TI Blvd, Dallas, Texas 75243, U.S.A.

ASIA PACIFIC

TI-Innovator™ Hub Software Single User License

IMPORTANT - Read this agreement ("Agreement") carefully before using the Texas Instruments Innovator Hub ("TIH"). The software program(s) installed on the TIH and materials accompanying it are licensed, not sold. By using the software program(s) contained on the TIH, you agree to be bound by the terms of this license. If you do not agree with the terms of this license, return the TIH and its package with all its contents to the place of purchase for a full refund.

The software program(s) installed on the TIH and any related documentation (collectively referred to as the Program) are licensed, not sold, by Texas Instruments Incorporated (TI) and/or any applicable licensors (collectively referred to as Licensor). Specific details of the license granted are set forth below.

SINGLE USER LICENSE

Licensor grants to you a personal, non-exclusive, non-transferable license to install and use the Program on a TIH. You may make one copy of the software for backup and archival purposes. You agree to reproduce all copyright and proprietary notices shown in the software and on the media. Unless otherwise expressly stated in the documentation, you may not duplicate such documentation.

You agree that you will not copy any idea or trade secrets relating to the Program, reverse engineer, reverse-assemble, reverse-compile or analyze the software program portion of the Program in whatever way. This license shall automatically terminate in the event you attempt to copy any idea or trade secrets relating to the Program, reverse engineer, reverse-assemble, reverse-compile or analyze

the software program portion of the Program or defeat any software protection mechanism contained within the software program portion of the Program. You may not sell, redistribute, rent, lease or otherwise transfer the Program or any copies, whether in whole or in part. You acknowledge that damages may not be sufficient remedy for any breach or threatened breach of this Agreement and TI is entitled to seek specific performance or injunctive relief (as appropriate) as a remedy for any breach or threatened breach by you or any other party, in addition to any other remedies available at law or in equity.

Additional Terms Applicable To The Holder Of A Single User License:

WARRANTY DISCLAIMER AND DAMAGES EXCLUSIONS AND LIMITATIONS

Limited Warranty. During the warranty period Licensor warrants that the Program, when properly installed, will substantially conform to the functional specifications set forth in the applicable user manual. Licensor does not warrant that the Program will meet your requirements or that operation of the Program will be uninterrupted or error free. The warranty period for the Program is two (2) years commencing on the date the license is acquired by the end user authorized under the single user license terms stipulated above. You must notify Licensor in writing of any nonconformity within the warranty period. This warranty shall not be valid if the Program has been subject to misuse, unauthorized modification or installation. Any modifications made to the Program by you are not included in this warranty.

Remedy. Licensor's entire liability and your exclusive remedy shall be, at Licensor's option, either: (a) refund of the price paid upon return of the Program to Licensor or (b) modification or replacement of the Program that does not meet this limited warranty, provided you have otherwise complied with this license.

THE WARRANTIES SET FORTH HEREIN ARE EXCLUSIVE AND APPLY SOLELY TO YOU, THE END-USER WHO LICENSED THE PROGRAM. LICENSOR MAKES NO OTHER WARRANTIES, EXPRESS, IMPLIED, OR STATUTORY, WITH RESPECT TO THE PROGRAM. LICENSOR SPECIFICALLY DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY, ACCURACY, COMPLETENESS, FITNESS FOR A PARTICULAR PURPOSE, AND NONINFRINGEMENT OF INTELLECTUAL PROPERTY. LICENSOR SHALL NOT BE RESPONSIBLE FOR ANY DAMAGES OR LOSSES CAUSED BY THE USE OF THE PROGRAM, OR SUFFERED OR INCURRED BY YOU OR ANY OTHER PARTY INCLUDING BUT NOT LIMITED TO SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF LICENSOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSSES.

IN JURISDICTIONS OUTSIDE THE U.S., THE EXCLUSION OF DAMAGES IN THE FOREGOING PARAGRAPH MAY NOT APPLY TO YOU. IN ANY SUCH CASE, HOWEVER, LICENSOR'S LIABILITY IS LIMITED TO TYPICAL, FORSEEABLE DAMAGES CAUSED BY THE LICENSED USE OF THE PROGRAM AND EXCLUDES ALL SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF LICENSOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, TO THE EXTENT PERMITTED BY APPLICABLE LAW.

LICENSOR'S TOTAL AGGREGATE LIABILITY UNDER THIS LICENSE IS LIMITED TO 500 (FIVE HUNDRED) US\$. THE ABOVE LIMITATIONS OF LIABILITY FOR DAMAGES DO NOT APPLY IN CASE OF CAUSATION OF BODILY HARM DUE TO LICENSOR'S FAULT, IN CASE OF DAMAGES DUE TO LICENSOR'S GROSS NEGLIGENCE OR INTENT OR IF LICENSOR IS LIABLE UNDER MANDATORY PRODUCT LIABILITY LAWS.

GENERAL

This Agreement will immediately terminate if you fail to comply with its terms. Upon termination of this Agreement, you agree to return or destroy the original package and all whole or partial copies of the Program in your possession and so certify in writing to TI.

The export and re-export of United States original software and documentation is subject to the Export Administration Act of 1969 as amended. Compliance with such regulations is your responsibility. You agree that you do not intend to nor will you, directly or indirectly, export, re-export or transmit the Program or technical data to any country to which such export, re-export or transmission is restricted by any applicable United States regulation or statute, without the proper written consent or license, if

required of the Bureau of Export Administration of the United States Department of Commerce, or such other governmental entity as may have jurisdiction over such export, re-export or transmission.

If the Program is provided to the U.S. Government pursuant to a solicitation issued on or after December 1, 1995, the Program is provided with the commercial license rights and restrictions described elsewhere herein. If the Program is provided to the U.S. Government pursuant to a solicitation issued prior to December 1, 1995, the Program is provided with "Restricted Rights" as provided for in FAR, 48 CFR 52.227-14 (JUNE 1987) or DFAR, 48 CFR 252.227-7013 (OCT 1988), as applicable.

This Agreement shall be governed by and interpreted in accordance with Swiss law. The United Nations Convention on Contracts for the International Sale of Goods shall not apply. If any provision in this Agreement or part of any provision shall be or become invalid, the other provisions as well as the other part of the provision shall remain valid.

This Agreement constitutes the entire agreement and understanding of you and TI. Any additions or modifications hereto must be made in writing and signed by a duly authorized TI representative. This also applies to any waiver of this requirement of written form.

Manufacturer is Texas Instruments Incorporated, 12500 TI Blvd. Dallas, Texas 75243, U.S.A.

EUROPE

TI-Innovator™ Hub Software Single User License

APPLICATION: This Single User License applies to TI-Innovator™ Hub obtained in any country for which no specifics set of license terms is provided herein.

IMPORTANT - Read this license ("License") carefully before using the Texas Instruments TI-Innovator™ Hub ("TIH"). By using the software program(s) pre-installed on the TIH, you agree to be bound by the terms of this License. If you do not agree with the terms of this License, return the TIH and its original package with all its contents to the place of purchase for a full refund. The package must be returned within 14 days from the date of purchase.

The software program(s) pre-installed on the TIH (the "Software") and any related documentation (collectively referred to as the "Program") are licensed by Texas Instruments Incorporated (TI). Specific details of the license granted are set forth below.

SINGLE USER LICENSE

(1) License

(1.1) TI grants to you a personal, non-exclusive license to use the Program on a TIH, transferable only as set forth in paragraph (1.3) below. Unless otherwise expressly stated in the documentation, you may not duplicate such documentation.

(1.2) You agree that you will not reverse-assemble or reverse-compile the Software or use any other technique to obtain the source code unless this is indispensable to obtain the information necessary to achieve the interoperability of an independently created computer program and provided that: (1) these acts are performed by you or on your behalf, (2) the information necessary to achieve interoperability has not previously been made available to you by TI within a reasonable time upon your request, and (3) these acts are confined to the parts of the Software which are necessary to achieve interoperability. The information thus obtained may only be used by you to achieve interoperability. TI shall be entitled to terminate this License for good cause with immediate effect in the event you breach the foregoing provisions or attempt any action that would constitute a breach of the foregoing provisions.

(1.3) You may not rent, lease or otherwise transfer the Program or any copies, whether in whole or in part to third parties. You may only sell the Program as part of the TIH and only if you cause your

purchaser to confirm in writing that the terms of the license set forth herein are binding upon the purchaser and if you keep no copies of the Program.

(2) Limited Claims in Case of Defects

(2.1) If during the limitation period in paragraph (2.5) below the Program shows a defect which already existed at the time of transfer of risk, TI will at its option and expense repair the defect or supply a replacement ("Subsequent Performance") or take back the TIH and refund the purchase price to you. Subsequent Performance shall be effected without a legal obligation. When bringing a warranty claim you must show proof of purchase.

(2.2) The Program shows a defect if it does not conform to the functional specification set forth in the applicable user manual.

(2.3) TI shall not be liable for any defects that are caused by neglect, misuse or mistreatment, including improper installation, operation, use, maintenance or testing, use in fields of application and environmental conditions other than those expressly specified by TI; and use in combination with other products not approved by TI for this purpose, or if the Program has been altered or modified in any way.

(2.4) If Subsequent Performance is not successful within a reasonable period of time, you shall, notwithstanding your claims for damages (which are subject to the Limitation of Liability Clause below), if any, be entitled to rescind the agreement for the purchase of the TIH or to claim a price reduction.

(2.5) The limitation period for warranty claims is one (1) year. For repaired Programs the remainder of the original limitation period shall run from the return of the repaired Program to you. For replaced Programs the limitation period shall start anew upon delivery of the replaced Program to you.

(2.6) If the analysis of an alleged defect shows that no defect exists, TI is entitled to charge for the failure analysis at TI's then applicable rates. In this case, shipment of the Program will be at your expense and risk.

(3) Intellectual Property Indemnification, Defects in Title

(3.1) Subject to paragraphs (3.2) and (3.3) and the Limitation of Liability Clause below and during the limitation period for warranty claims (paragraph (2.5) of the Limited Claims in Case of Defects Clause above), TI will indemnify you against any damages, liabilities or costs finally awarded against you, or agreed to by TI as settlement or compromise, insofar as such claim is based on an allegation that the Program directly infringes any United States, Canadian, Japanese, Swiss or European Union member state patent, copyright, or other intellectual property right; provided (i) TI is promptly informed and, where applicable, furnished a copy of such claim, (ii) TI is given all evidence in your possession, (iii) TI is given reasonable assistance in and sole control of the defense thereof, to which TI is entitled but not obliged, and all negotiations for its settlement or compromise, and (iv) you do not concede an infringement of intellectual property rights vis-à-vis third parties. If you discontinue the use of the Program for mitigation of damages or other important reasons, you are obligated to point out to the third party claimant that the discontinuation of use does not constitute an acknowledgement of an infringement of such third party's intellectual property rights.

(3.2) In the event of an allegation for which TI is obligated to indemnify you pursuant to paragraph (3.1) above, TI shall at its option: (i) obtain a license that allows you to continue the use of the Program, or (ii) replace or modify the Program so as to be non-infringing, but in a manner that does not materially affect the functionality of the Program, or (iii) if neither (i) nor (ii) is available to TI at a commercially reasonable expense then refund to you the purchase price and the transportation costs of the Program. If TI elects the option set forth in clause (iii) above, you shall return to TI any and all products remaining in your possession, custody or control. The foregoing shall be TI's exclusive liability safe for any restricted claims for damages in accordance with the Limitation of Liability Clause below.

(3.3) TI shall have no liability for any costs, losses or damages resulting from your willful acts, or any settlement or compromise incurred or made by you without TI's prior written consent. TI shall have no obligation to defend and no liability for any costs, losses or damages, to the extent that an infringement allegation is based upon: (i) your use of the Program in combination with any other product, software or equipment; (ii) your use of the Program in a manner or for an application other than for which it was designed or intended, regardless of whether TI was aware of or had been notified of such use (unless TI has approved such use in writing); or (iii) your modifications to the Program (the actions set forth in (i)

through (iii) above entitle TI to respective claims against you which are individually and collectively referred to herein as "Other Claims").

(3.4) You shall indemnify and hold TI harmless against any damages, liabilities or costs finally awarded against TI or agreed to by you as settlement or compromise, and will defend any claim brought against TI insofar as such claim is based on an allegation arising from Other Claims.

(3.5) This Clause states the sole liability of TI and you for intellectual property rights infringement.

(4) Limitation of Liability

(4.1) TI shall be liable without restriction for damages caused by gross negligence and willful intent. Any further liability of TI shall be excluded.

(4.2) With the exception of liability under product liability law, for the breach of a guarantee for the quality of the Program, for fraudulently concealed defects and for injury to life, body or health, the above limitations of liability shall apply to all claims for damages, irrespective of their legal basis.

(4.3) The above limitations of liability also apply in case you bring a claim against TI's employees or agents.

GENERAL

(1) TI may terminate this License for good cause with immediate effect if you fail to comply with its terms. Upon termination of this License, you agree to return or destroy the original package and all whole or partial copies of the Program in your possession and so certify in writing to TI.

(2) The export and re-export of the Program is subject to the export control laws of the country in which you bought the TIH and the United States Export Administration Act of 1969 as amended. Compliance with such regulations is your responsibility. You agree that you do not intend to nor will you, directly or indirectly, export, relicense export or transmit the Program or technical data to any country to which such export, re-export or transmission is restricted by any applicable regulation or statute of the country in which you bought the TIH or of the United States, without the proper written consent or license, if required of the competent authority in the country in which you bought the TIH and/or the Bureau of Industry and Security of the United States Department of Commerce.

(3) This License shall be governed by and interpreted in accordance with Swiss law. The United Nations Convention on Contracts for the International Sale of Goods shall not apply.

(4) If any provision in this License or part of any provision shall be or become invalid, the other provisions as well as the other part of the provision shall remain valid.

(5) This License constitutes the entire agreement and understanding of you and TI. Any additions or modifications hereto must be made in writing and signed by a duly authorized TI representative. This also applies to any waiver of this requirement of written form.

(6) Manufacturer is Texas Instruments Incorporated, 12500 TI Blvd. Dallas, Texas 75243, U.S.A.

The following program files are covered by and distributed under the BSD license.

Wire

Tone

BSD License follows:

```
/*  
 * Copyright (c) 2015, Texas Instruments Incorporated  
 * All rights reserved.  
 *  
 * Redistribution and use in source and binary forms, with or without modification, are permitted provided  
 * that the following conditions are met:  
 *  
 * * Redistributions of source code must retain the above copyright notice, this list of conditions and the  
 * following disclaimer.  
 *  
 * * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and  
 * the following disclaimer in the documentation and/or other materials provided with the distribution.  
 *  
 * * Neither the name of Texas Instruments Incorporated nor the names of its contributors may be used  
 * to endorse or promote products derived from this software without specific prior written permission.  
 *  
 * THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY  
 * EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES  
 * OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT  
 * SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT,  
 * INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED  
 * TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR  
 * BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN  
 * CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY  
 * WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.  
 */
```

End of BSD license.

General Information

Texas Instruments Support and Service

General Information: North and South America

Home Page:	education.ti.com
KnowledgeBase and e-mail inquiries:	education.ti.com/support
Phone:	(800) TI-CARES / (800) 842-2737 For North and South America and U.S. Territories
International contact information:	education.ti.com/support/worldwide

For Technical Support

Knowledge Base and support by e-mail:	education.ti.com/support or ti-cares@ti.com
Phone:	(866) 846-2844

For Product (Hardware) Service

Customers in the U.S., Canada, Mexico, and U.S. territories: Always contact Texas Instruments Customer Support before returning a product for service.

For All Other Countries:

For general information

For more information about TI products and services, contact TI by e-mail or visit the TI Internet address.

E-mail inquiries:	ti-cares@ti.com
Home Page:	education.ti.com

Service and Warranty Information

For information about the length and terms of the warranty or about product service, refer to the warranty statement enclosed with this product or contact your local Texas Instruments retailer/distributor.



Texas Instruments U.S.A.
12500 TI Blvd.
Dallas, TX 75243

Texas Instruments Holland B.V.
Rutherfordweg 102
3542 CG Utrecht - The Netherlands

Printed by: