





TI-Nspire™ family of graphing calculators*

Test preparation: Press-to-Test


For State of Texas Assessment of Academic Readiness (STAAR®) tests that require the use of a graphing calculator.

Before the exam, put the calculator in Press-to-Test mode:

Enabling Press-to-Test will block access during the exam to pre-existing programs, documents, files and folders, applications, data and pictures.

Screens may vary slightly by model and operating system (OS).

- 1) Ensure the graphing calculator is turned off. Press [atr] [as on keys.
- 2) Press and hold down esc and keys simultaneously until the **Press-to-Test** screen is displayed.



By default, all restrictions are selected.


- 3) Deselect all: press ctrl then A.
- 4) Use arrow keys or the to scroll the list of restrictions. When the following restrictions are highlighted, press to select the

- restriction. (**Do not press** enter to select.)
- » Limit geometry functions
- » Disable inequality graphing
- » Disable implicit graphing, conic templates, conic analysis and geometric conics
- 5) Enable Press-to-Test by pressing

 tab to select Enter Press-to-Test
 then press [enter].
- 6) The graphing calculator will reboot and confirm restrictions. Select **0K** to continue to the home screen.



7) When Press-to-Test is enabled, a lock icon will display in the upper right corner of the home screen.



An LED near the graphing calculator's mini USB port will:

- Flash green to indicate all restrictions (default) are selected
- » Flash amber to indicate one or more restrictions were disabled

If the graphing calculator is in Press-to-Test mode and is to be used in subsequent exams, you can reset Press-to-Test to clear all data and files created during the previous exam.

If the graphing calculator will not be used in subsequent exams, exiting Press-to-Test restores system settings and files that were restricted and clears all data and files created while in Press-to-Test mode.

For additional help, please contact **1.800.TI.CARES.**

After each exam, reset Press-to-Test mode:

- 1) Ensure the graphing calculator is turned off. Press @ keys.
- 2) Press and hold down esc and a mem keys simultaneously until the **Press-to-Test** screen is displayed.
- 3) Select **Reset Press-to-Test** and then press enter.


After the exam, exit Press-to-Test mode:

- Connect the graphing calculator to a similar model in the TI-Nspire[™] family using the USB unit-to-unit cable.
- 2) Press and for the home screen.

 Press 2 to select My Documents,

 or Browse.

3) Press doc and select 9: Press-to-Test. Press enter.



4) Select 1: Exit Press-to-Test. Press [enter].

This handheld is in Press-to-Test mode.

Disable function and conic grab and move.


and disable change of equation form

Pre-existing content is disabled

Press-to-Test

Angle Setting: Degree

Restrictions include:



The graphing calculator will reboot out of Press-to-Test mode.

