# How to Update the TI-84+CE Operating System and Install Apps

To check the current calculator operating system, press [2nd][MEM] (above [+] key) and select 1: About.

**TRANSFER FROM COMPUTER TO CALCULATOR**

1. Download the OS file from the TI website, now available as an "OS and Apps Bundle" which is a single file to update everything at the same time.
   https://education.ti.com/en/software/update/download-84ce?soft=84-pl-ce

   Note that the TI-84+ has a different OS than the CE. Apps must be updated separately.

2. Download the TI-Connect CE software if needed.

3. Connect your TI-84 Plus CE to your computer and open your TI Connect™ CE software. You may connect and update as many calculators as the available USB ports on your computer allow.

4. Drag the new OS and apps bundle file from the folder on your computer to the TI Connect™ CE software.

**TRANSFER FROM CALCULATOR TO CALCULATOR**

1. Press [2nd][LINK] (above [X,T,Θ,n] key) and select Send OS on the sending calculator.

2. On the receiving calculator, the RAM will be erased. Programs and Appvars should be archived before updating OS.

   Do not disconnect the cable at any time while updating an operating system or installing Apps to a handheld calculator.

   Do not attempt to update an operating system if your calculator shows a "low battery" message.

3. To send an App, Program, List, etc., press [2nd][LINK]
   a. On the Receiving calculator, select "Receive" so the calculator is "Waiting"
   b. On the Sending calculator, navigate to the desire item(s) and press [ENTER] to select them. Then use the right arrow to choose "Transmit".

   If there is any problem transmitting, press the ON button to break out of the transmission.

The TI-84 Plus USB link port is located at the top right edge of the graphing calculator.

1. Firmly insert either end of the USB unit-to-unit cable into the USB port.
2. Insert the other end of the cable into the other graphing calculator's USB port.

If using the TI-84 Plus CE, the USB port is on the right side of the calculator.